

Compression Strap Installation Instructions

For converting your KinderShuttle to A BaseCamp Sled System

Included in this Kit: 1 Duffel Bag; 3 Sets of compressions straps; 6 Mounting brackets with 1" welded wire loops; 6 Sets mounting hardware.



1. Located on each side of your sled hull are pre-molded drill points. Use the supplied drill bit to drill the 3 drill points, (marked by the arrows in the photo above), on each side of the sled. There may be other drill points, just drill the 3 marked on either side.



2. Place a 1/2" pan head machine screw through a 1" fender washer and through each of the drilled holes from the **inside** of the sled hull. Installing the screws from the inside reduces wear on the duffel bag.



3. Place the wire loop bracket over the end of the screw, on the **outside** of the sled hull. Start the nylox nut onto the threads. Use a phillips screw driver and wrench or pliers to snugly tighten the nut.

Questions? sleds@wildernessengineering.com
1-888-553-5207